


Assebly Instruction

Please read the assembly instruction carefully before assembling.

Kindly reminder:

The loaction requirements of disassembling products are accurate, when assembling certain parts, please do not fully tighten the screws in the begining to to allow slighty adjustment with other parts.

Adult assembly required. Assemble on soft surface to prevent damage to the product finish. DO NOT use power tools.















Maintance


Check bolts/screw periodically and tighten if necessary.

Warning: Should this product become damage, and/or components are broken or missing, DO NOT USE.

Component list


① Top panel  1PC	② Bottom panel  1PC	③ Side panel  2PCS	④ Front top bar  1PC
⑤ Wing  2PCS	⑥ Front middle bar  3PCS	⑦ Front rear bar  1PCS	⑧ rear bar  1PC
⑨ Drawer face  4PCS	⑩ Drawer rear panel  4PCS	⑪ Drawer Side panel  8PCS	⑫ Drawer bottom panel  4PCS
⑬ Handle  4PCS			

Hardware list

A Cam nut  18PCS	B Cam bolt  18PCS	C Wood dowel  ∅8*30 30PCS	D Screw  M4*35 40PCS
E Screw  M4*10 16PCS	F Caster  4PCS	G Screw  M6*25 4PCS	


Step: 1

C  6PCS



Step: 2

D  8PCS




Step: 3


A  5PCS

B  5PCS


C  5PCS




1








2



3




4




Step: 4

- A 5PCS
- B 5PCS
- C 5PCS




Step: 5

- A 4PCS
- B 4PCS
- C 4PCS




Step: 6

- E 16PCS
- F 4PCS




Step: 7




Step: 8

- A  4PCS
B  4PCS
C  4PCS




Step: 9

- G  4PCS




Step: 10

- D  16PCS




Step: 11



Step: 12

D  16PCS



Step: 13

C  8PCS

