

# Cabela's®



(Actual safe model, size, color and specifications may vary.)

## OWNER'S MANUAL

## LIBERTY SAFE AND SECURITY PRODUCTS' LIMITED LIFETIME END CUSTOMER WARRANTY

**Limited Lifetime Warranty:** Liberty Safe and Security Products, Inc. (Liberty) is proud of the workmanship of the product you have just purchased. Liberty warrants that each new safe will be free from defects in material and workmanship for the lifetime of the original purchaser. If there is a defect in either materials or workmanship during your lifetime, we will repair or replace your safe at no cost to purchaser within the United States and Canada. Liberty will also repair or replace at no cost to the warranted party, any warranted safe that is damaged during a fire, break-in or break-in attempt within the United States and Canada during the lifetime of the original purchaser if the homeowner's insurance policy will not cover the damage. The lifetime warranty does not include the lock or painted surface.

**Outside of the United States & Canada:** Liberty warrants that each new safe will be free from defects in material and workmanship of the safe mechanism for the lifetime of the original purchaser. If there is a defect in either materials or workmanship in the mechanism during your lifetime, we will provide replacement parts of like type and function for your safe at no cost to purchaser. However, service costs will be the responsibility of the safe owner. Customers outside of the United States and Canada are responsible for all freight charges in safes replaced under the fire and burglary warranty.

**Lock and Painted Surface Warranty:** Locks and painted surfaces are warranted to be free from defects in workmanship and materials for a period of five years from the date of purchase. Within this five-year period Liberty will repair (including labor within the United States and Canada) and/or provide parts of like size and type at no cost to the warranted party.

**Electrical Items Warranty:** Light fixtures, transformers, cords, and light switches are warranted to be free from defects in workmanship and materials for a period of 1 year from the date of purchase.

Liberty's obligation under the Limited Lifetime Warranty is limited to the repair (including labor within the United States and Canada) or replacement of any product that proves to be defective or damaged during a fire, break-in or break-in attempt, with a product of like size and type. Claims shall be made under this warranty by calling 800-247-5625 or writing to Liberty Safe and Security Products, 1199 West Utah Avenue, Payson, Utah 84651. Any claims made for fire, break-in or break-in attempts must be accompanied by a copy of your homeowner's insurance statement of coverage, and a report made by the police or fire department. A claim must be made within six months of the break-in. Liberty takes seriously its obligation to stand behind its product with this warranty as long as the safe is properly installed and cared for as instructed in the Owner's Use and Care Manual. The warranty does not apply to safes or parts that have been misused, neglected or subjected to unusual or extreme conditions and/or environments, or to unreasonable wear and tear. Changing or modifying the safe in ways that affect its intended use will void this warranty. As a special service to you, the limited lifetime warranty can be transferred to subsequent purchasers or owners with the prior written consent from Liberty. Simply contact our Customer service team with your request. Liberty reserves the right to deny a request or transfer for any reason.

**Limitation of Remedies:** In no case shall Liberty be liable for any special, incidental, or consequential damages based upon breach of warranty, breach of contract, negligence, strict tort, or any other legal theory. Such damages include, but are not limited to, loss of profits, loss of savings or revenue, loss of the contents of the safe or vault door, loss of use of the safe or vault door, or any associated equipment, cost of capital, cost of any substitute equipment, facilities or services, downtime, the claims of third parties including customers, and injury to property.

**Warranty Registration:** Online registration must also be completed within (30) days of purchase. Failure to register the product shall void any warranty.

**No Other Warranties:** This agreement is understood to be the complete and exclusive agreement between the parties, superseding all prior agreements, oral or written, and all other communications between the parties relating to the subject matter of this agreement. No employee of Liberty or any other party is authorized to make any warranty in addition to those made in this agreement.

**THIS WARRANTY PERTAINS ONLY TO THE LIBERTY SAFE ITSELF AND DOES NOT EXTEND TO THE CONTENTS OF THE SAFE. FOR OPTIMAL SECURITY AND PROTECTION, SAFES SHOULD BE BOLTED TO THE FLOOR. PLEASE REFER TO THE USE & CARE MANUAL FOR DETAILS ON ANCHORING YOUR SAFE TO THE FLOOR.**

**Disclaimer of Warranty:**

THE ABOVE WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH EXTENDS BEYOND THE WARRANTY SPECIFIED ABOVE, AND IN NO EVENT SHALL THIS WARRANTY BE DEEMED TO COVER INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY KIND.

**Venue and Choice of Law:** Any claims arising from this limited warranty shall be resolved in the State of Utah and Utah law will apply to any dispute

**Congratulations** on your purchase of your new Cabela's security safe made by Liberty Safe! To insure proper set up and installation, **PLEASE READ THIS USE AND CARE MANUAL** before opening your safe.



**SAFETY PRECAUTIONS**

The safe door is heavy. Do not open the door with the safe on an uneven or unstable floor. Hanging on an open door may cause the safe to tip forward when not lag-bolted to the floor, resulting in serious injury or death to yourself or others. If you have or have occasion to have small children in your home, please make sure you never leave your safe unsecured. It is possible for small children to climb inside your safe and become locked in. This could result in serious injury or death.

**INSPECT YOUR SAFE**

Inspect your safe for shipping damage as soon as you receive it. If you find any damage, please contact the delivery company or retailer immediately. Any damage not noted upon delivery must be reported within fifteen (15) days or there will be no recourse.

**SERIAL NUMBER & MASTER COMBINATION** (See opening instructions before proceeding)

If your safe has been installed with an electronic lock, use the Electronic Opening Instructions on page 8 before proceeding.

Place serial number and  
combination here

Your safe's **serial number** is located in two (2) locations on the safe. One is located on the top of the safe, front right corner. The second is located just inside the door by the locking bars. Compare the serial number in this manual with the serial number on the safe. All serial numbers should match. If they do not, contact your local dealer or Liberty Safe immediately. **You will need your safe serial number when contacting customer service about your safe.**

**PLEASE NOTE:** Record your safe's serial number and combination and store in a secure location **OTHER THAN YOUR SAFE.**

To register your warranty go to

**WWW.LIBERTYSAFE.COM**

Click on the Tools button on the top of the home page and select Warranty Registration to complete the registration and print out warranty confirmation.

**You will need the serial number of your safe to register**

**TABLE OF CONTENTS**

Safety Pre-Cautions.....2

Registration Info.....2

Serial Number and Combination.....2

Table of Contents.....3

Opening Your Safe.....4

Combination Lock Opening Instructions.....4

Electronic Lock Opening Instructions.....5

Moving Your Safe.....6

Placement of Your Safe.....6

Removing the Safe from Pallet.....7

Anchoring Your Safe.....7

Using and Maintaining Your Safe.....7

Loading Your Safe.....7

Lost Combination.....8

Troubleshooting Guide.....8-9

Frequently Asked Questions.....9

Warranty Claims and Repairs.....10

## OPENING YOUR SAFE

### OPENING SAFE FOR THE FIRST TIME

**NOTICE:** Your safe is shipped with the combination open and dial fixed with rubber gum. You will need to do this before verifying your combination. It is preferred to verify your safe combination with the door open. If there are problems, it is easier to service the lock or mechanism with the door open. Before verifying your combination, you will need to extend the door bolts while the door is open. Next remove the rubber gum from the dial so that the dial turns freely. Keep door open. You can now verify your combination.

### VERIFYING THE COMBINATION

The combination lock on your safe has been set randomly at the factory. After completely dialing the combination provided with your safe, turn the safe handle and open door. With the door open it is recommended that you verify the combination opens a few times before using the safe. It is also strongly recommended to do this again after moving the safe to its permanent location.

### COMBINATION LOCK OPENING INSTRUCTIONS

The lock requires accurate alignment with the index mark (located at twelve noon on the dial ring). Always turn the dial slowly and steadily when entering your combination to avoid dialing past your numbers. **Never spin the dial rapidly back and forth as this may cause damage to the lock.** If you go past any number - even if by only a half a number - the entire combination must be re-dialed. To verify your combination, follow the four steps below. Copy your combination numbers from page 2 to the spaces below.



**Step 1**  
Turn counterclockwise (LEFT) at least 4 times aligning the 1st # to the index at 12 o'clock.

1st # \_\_\_\_\_



**Step 2**  
Turn clockwise (RIGHT) passing the 2nd # twice. Stop on the 2nd # the third time it aligns with the index at 12 o'clock.

2nd # \_\_\_\_\_



**Step 3**  
Turn counterclockwise (LEFT) passing the 3rd number once. Stop on the 3rd # the second time it aligns with the index at 12 o'clock.

3rd # \_\_\_\_\_



**Step 4**  
Turn clockwise (RIGHT) until the dial stops (about 87). You will feel some resistance at about 95. Keep turning until the dial completely stops at about 87.

**Step 5** – If combination is entered correctly, you will be able to easily turn the safe handle and open the safe.

**⚠ IF COMBINATION DOES NOT WORK, DO NOT CLOSE THE DOOR! Try Again. Refer to the TROUBLE SHOOTING GUIDE in the back of this manual for more help.**

**Electronic Locks**

Your safe may have one of the following two model electronic locks. Be sure to choose the correct model instructions before attempting to use your electronic safe lock.

**SafeLogic TopLit Electronic Lock**



**⚠ WARNING!** All Electronic locks are set at the factory to 123456. For security purposes, you should change this combination to your own, new combination number. (See instructions below)

**⚠** Before entering your electronic lock combination, center the handle between left and right stop points. **If the handle or locking mechanism is putting pressure on the lock, it may not open.**

**⚠** Before entering your electronic lock combination, remove any static charge you may have by touching your finger to the body of the safe. **Discharging static electricity into the lock can damage it and prevent proper operation**

**Read Before opening your electronic lock for the first time**

Enter the factory set 6 digit master combination (1,2,3,4,5,6 ). When each number is pressed, the lock will chirp and the blue LED on the keypad will momentarily light up. After entry of a valid code a single beep will follow, indicating the lock has opened and it is okay to turn the handle and open the safe door. You have **6 seconds** to turn the handle. If you wait longer than 6 seconds, the lock will re-lock and you will need to enter the code again. If you experience any problems opening your safe, refer to the Trouble Shooting section in this manual. If you pause more than 15 seconds between each number the lock will assume you do not wish to continue and will reset itself.

**As a security feature, if 4 incorrect codes are entered in a row, your lock will stop accepting combinations for a period up to 5 minutes.** To lock your safe, close the door and turn the handle fully to the closing position. You should hear the lock 'click' indicating the lock bolt has dropped into place. Check by trying to turn the handle

**Changing an Existing Code on SafeLogic TopLit Lock**

Press **000000** ( \_ \_ \_ \_ \_ ) ( \_ \_ \_ \_ \_ ) ( \_ \_ \_ \_ \_ )   
existing code                      new code                      new code

After each time the combination is entered, the lock chirps to acknowledge the entry. Wait for the chirps before proceeding. If a series of 3 chirps sounds after entry, the new user code will not be accepted and the old code will remain. You will need to start over.

For example, if you want to set a new code to a code of 4 4 6 6 3 3 and the existing code is 1 2 3 4 5 6, you will use the following procedure:

Press **000000** ( 1 2 3 4 5 6 ) ( 4 4 6 6 3 3 ) ( 4 4 6 6 3 3 )   
existing code                      new code                      new code

This procedure will change or set the existing code to: 4 4 6 6 3 3

**⚠ Note:** Verify the new code at least 3 times before closing the door to make sure the code has been programmed correctly.

### **CHANGING BATTERIES IN ELECTRONIC LOCK**

Battery life is based on how much the electronic lock is used. The lock will emit several short chirps when battery power is getting low. Liberty Safe only recommends using **Duracell® 9V Alkaline Batteries** for best performance. The memory chip in the lock itself retains the lock codes during battery changes and even if the battery goes dead for an extended period of time. A weak battery may cause the lock to not open, even though beeps occur. Replace with fresh batteries at regular intervals to insure best performance.

### **BATTERY REPLACEMENT – SafeLogic TopLit Electronic Keypad**

**Step 1** - Turn the housing ring counterclockwise until it cannot move (about 20°), then pull it off from the entrypad base.

**Step 2** - Push the battery from the bottom left side of the entrypad and unsnap the battery from the connector.

**Step 3** - Snap a new 9V alkaline battery onto the battery clip and put it back into the compartment by pushing it from the right side. **Note: Tuck the cable into the compartment and make sure the cable does not get caught in the housing ring.**

**Step 4** - There are three alignment tabs on the inside of the housing ring and three corresponding grooves on the entrypad base. Locate the housing ring and slide it onto the base.

**Step 5** – Then turn the ring clockwise until a click sounds.

## **MOVING YOUR SAFE**



### **SAFETY PRECAUTIONS**

Before moving the safe, make sure you have completely tested the combination and lock to assure it will open properly prior to removing the safe from the pallet and to its final location. Safe doors are NOT designed to be removed due to possible serious injury.

(Removing the door will void your safes warranty.) Never move the safe with the door open. Do not open the door with safe lying down. Safes are very heavy and awkward to handle. Only use of proper moving equipment by a trained professional is recommended. Using a standard refrigerator dolly is very dangerous and can cause injury or death.

### **PLACEMENT OF YOUR SAFE**

Before moving your safe, verify the load bearing weight of the floors and stairs, and types of flooring the safe will be moved over (tile, wood, and other flooring can be damaged by the weight of the safe). To determine whether or not your safe will make it through doorways, stairs or corners, take the empty safe box and see if it will fit all the way through to its final location.



**Proper installation and anchoring are critical to the security of your safe.** Make sure you consider the following:

- Install near a load-bearing wall as a precaution to supporting the weight of the safe.
- To help protect the exterior finish of your safe, install inside your home in a dry location where there is climate control (heat in the winter and cooling in the summer).
- The safes fire rating depends upon the number of layers of fireboard and BTU rating. Generally speaking, fire safes perform better in lower levels of a home (like the basement) where fire temperatures are lower. Additionally, placement of your safe away from potential hot spots (areas where flammable materials are stored) will improve your chances that your safe and its contents will perform better in a home fire. No safe is completely fireproof. If the fire reaches a high enough temperature for long periods, fire damage may occur.
- To store photographs, negatives, CD's or other electronic media, a Media Cooler Storage unit inside your safe is recommended for heat sensitive items.

### **REMOVING THE SAFE FROM PALLET**

With the safe upright and open, fold back the carpeted floor and pry up the black plastic caps to expose the lag bolts. Use a 7/16 socket & ratchet to remove the bolts. **Caution: Have someone steady the safe while removing the safe from the pallet to prevent the safe from tipping off the pallet.** To prevent accidental opening while removing the safe from the pallet and to its final location, close the door and rotate the handle extending the locking bars. Make sure you have adequate help to move the safe off its pallet. Carefully slide the safe off the pallet until one edge is resting on the floor. While the safe is tilted on its edge, remove the pallet out from under the safe. Carefully lower the safe back to its upright position.

### **ANCHORING YOUR SAFE**

To achieve the highest level of security it is **STRONGLY RECOMMENDED** that you anchor your safe securely to the floor. We recommend placing a protective barrier (such as a piece of carpet, treated wood or rubber mat) between the safe and floor to prevent scratching of the safe surface, which could lead to rust. Before anchoring safe, make sure the safe is level. Use redwood door shims to adjust safe level so the door has the desired swing. Use appropriate hardware for the wood or cement surface you are anchoring to. Anchoring kits with instructions are available from your dealer. Given enough time it is possible for a thief to break into a safe. Securing it to the floor helps secure and prevent removal of the safe by thieves.

## **USING & MAINTAINING YOUR SAFE**

### **LOADING YOUR SAFE**

- When putting guns into your safe, make sure they rest securely against the cutouts provided to prevent accidental tipping when the door is closed.
- If you are storing electronic media, use a Media Cooler to provide additional protection (See your local dealer or visit [www.libertysafe.com](http://www.libertysafe.com)).
- Do not put anything in your safe that will put pressure against the door, or the locking bars when the door is closed.
- If you live in a humid environment, it is recommended that you use a **dehumidifier** or **desiccant** to protect the contents from rust or mildew. Dehumidifiers and other moisture reducing products suitable for your safe are available from your dealer. Do not install or store these devices, or any other personal contents, near the locking bars on the door as this could interfere with the function of the mechanism in the door.

### **CLEANING AND MAINTAINING YOUR SAFE**

- **The Combination Lock** – The combination lock does not require any type of service.
- **Internal Locking Mechanism** – The advanced locking mechanism requires no maintenance. Opening the door panel of your safe by anyone other than a certified lock or safe technician may void your warranty.
- **Exterior** – Use a soft, non-abrasive cloth dampened with water to clean the textured surface. Other materials may cloud or scratch the finish of your safe:
  - Logos and other graphic images must be wiped gently. Never rub or polish
  - The lock and handle have a protective coating to prevent tarnish. **DO NOT** use metal polishes or solvents for cleaning. Simply wipe off with a soft cloth.
  - Scratches and other blemishes may be touched up with a paint touch-up kit available from your dealer.
- **Door Seal** – The door seal does not need maintenance unless it is ripped or destroyed. If the seal becomes damaged, call for replacement pieces.

### LOST COMBINATION

The lock on your safe has been set with a randomly selected combination at the time of manufacturing. As part of our continuing service, a record of your combination by serial number is kept on file. If you lose your combination, you can retrieve a copy for a \$25.00 research fee. A Combination request form must be filled out and faxed along with a copy of the sales receipt to: (801) 465-2712. You can print a form from our website [www.libertysafe.com](http://www.libertysafe.com) under the Support tab or have one faxed or mailed by calling our toll free customer service line at (800) 247-5625, and press 4.

### TROUBLE SHOOTING

<u>Problem</u>	<u>Possible Solution</u>
<b>Combination Will Not Open the Safe</b>	<p>Check lock-bolt pressure. Some free play should exist in the handle, left to right.</p> <ol style="list-style-type: none"><li>1. Redial the complete combination stopping on the third number. Hold the dial, shake the handle back and forth. <b>PLEASE NOTE:</b> If your lock still does not open, it is possible that one or more of your numbers may be off slightly from those shown in this manual.</li><li>2. Try dialing 1 number up or 1 down from each number in the combination. If it opens with a new number, update your combination in this book and report it to Liberty Safe (800) 247-5625, Press 0.</li><li>3. Try pulling out on the dial while dialing the combination.</li></ol>
<b>Combination Opens the Safe Intermittently</b>	<p>Check lock-bolt pressure. Some free play should exist in the handle, left to right. Try dialing the combination again. Bolt pressure may be due to out of place interior shelves or improper personal storage (i.e. gun barrels, items too big for shelves).</p>
<b>Combination Dial Is Tight or Will Not Turn</b>	<p>Check lock-bolt pressure. Some free play should exist in the handle, left to right. Bolt pressure may be due to out of place interior shelves or improper personal storage. Make sure the locking bars are in the fully extended position with the door completely closed or completely open. Normally dial tightness varies from safe to safe. Tightness of dial may increase or decrease as dial is being turned.</p>
<b>Combination Works But Handle Will Not Turn</b>	<p>Corner protectors (packaging material) may cause undue pressure on the locking bolts. To alleviate the pressure push in on the door while turning the handle until resistance decreases, then pull to open the safe. If the handle turns partially the bars may be jammed or caught up. Try rotating the handle back and forth (left to right) until the bars free up.</p>

**Combination Works and Handle Turns But Safe Will Not Open**

Verify that the handle has been completely rotated before opening the door. Check the **5/16" Allen set screw**, located on the face of the handle under the black plastic cover, for tightness. Some safes are installed with a unique handle clutch mechanism. Improper personal storage or excess door adjustment may cause clutch to temporarily engage. Push in on the door while turning the handle, and when resistance decreases, pull to open.

**Door Will Not Shut**

Verify that the lock is unlocked and the locking bars are fully retracted. Make sure the interior shelves are pushed back as far as possible. The handle should travel the same distance with the door closed as it does with the door open all of the way.

**FREQUENTLY ASKED QUESTIONS**

**Q. Can I change the safe's combination?**

A. The combination on mechanical dial combination locks cannot be changed.

**Q. Why is the handle pointing in a different direction than it used to be?**

A. The handle has a built in clutch mechanism. When the handle is forced it will slip left, or right. To reset it simply force it back to its original position when locked.

**Q. What if I lose my combination?**

A. If you lose your combination, you can retrieve a copy for a \$25.00 research fee. A Combination request form must be filled out and faxed along with a copy of the sales receipt to: **(801) 465-2712**. You can print a form from our website [www.libertysafe.com](http://www.libertysafe.com) under the Support tab or have one faxed or mailed by calling our toll free customer service line at (800) 247-5625, and press 4.

**Q. Who do I contact if I need service for my safe?**

A. If you need service for your safe, please contact Liberty Safe Customer Service by calling (800) 247-5625 Monday - Friday 8:00am - 5:00pm MST

## **Warranty Claims and Repairs**

### **WARRANTY CLAIMS**

Please read carefully the safe warranty that accompanied your safe, located on the cover of this manual. If you encounter a problem that falls under the warranty coverage, simply call one of our representatives at (800) 247-5625, press 0. You will be required to provide the serial number and proof of ownership if you have not registered your safe or mailed in your warranty registration.

### **WARRANTY REPAIRS**

Repairs to your safe covered under your warranty should not be performed without the pre-authorization of a Liberty customer service representative. If there are any issues regarding your safe please contact a Liberty Safe customer service representative at (800) 247-5625. Solutions to frequently asked questions and issues can also be found in Trouble Shooting Guide in this booklet or on line at [www.libertysafe.com](http://www.libertysafe.com). The cost of any repairs performed without pre-authorization will be the sole responsibility of the owner.

### **WATER DAMAGE**

Your safe is not waterproof. Should your safe be exposed to water, the fire insulation of your safe will be compromised. Do not continue to store items in a safe that has been compromised by water. You should purchase a replacement model for continued fire protection. In the event of flooding or water damage, make sure to have your safe opened as quickly as possible. If your safe included firearms, remove them and have them cleaned and lubricated immediately. Damage to the safe from water is not included in the limited life-time warranty.

### **INSURANCE COVERAGE**

**i** **LIBERTY SAFE DOES NOT INSURE THE CONTENTS OF YOUR SAFE.** A homeowners policy or other insurance coverage should be purchased in an amount sufficient to cover the contents. Most homeowners policies require the purchase of riders or endorsements on items such as guns, jewelry coins and other valuable collectibles. Should damage occur to your valuables, a claim should be made with your homeowners insurance. Check with your local insurance company for possible discounts that may be available with your purchase.

---

## **NOTES:**

*Cabela's*®

---

Liberty Safe and Security Products, Inc.  
1199 West Utah Avenue Payson, UT 84651  
800.247.5625